

# Installation Guides

## Single-Lid Wunder-Covers

### Step 1

Set the frame to the desired level. Orientate to best suit the pattern of the pavers (optional). Frame must be fully supported including internal flanges & gussets.



### Step 2

Plaster all gaps. Leave sufficient depth for pavers to fit over external flanges. Once the plaster is firm, the pavers can be laid and cut neatly to the edge of the frame



### Step 3

Insert lid. Screed sand, lay and cut pavers as normal.



### Step 4

Fill Joints with dry sand. Compact carefully in the usual manner.



# Multi-lid Wunder-Cover

## Installation Guide

All work must be undertaken in a tradesman-like manner in accordance with local health and safety requirements, along with relevant standards.

### Step 1

Set the frame to the desired level. Orientate to best suit the pattern of the pavers (optional). Frame must be fully supported.



### Step 2

Pavers laid and cut neatly to the edge of the frame.



### Step 3

Once concrete is firm, replace trays.



### Step 4

Cut pavers to fit trays.



